

Aline this blue edge with jig edge



## Pricking Jig endstop drilling template

Instructions:-

Print out this drawing full size.

Cut along blue line.

Fold along the FOLD HERE line.

Place fold crease at bottom of jig ( into the vee ) and aline edge with the jig edge as shown.

Use the hole centres ( red crosses ) to mark the position of the holes Push a pen through the paper.

Drill 6-7mm diameter holes at these locations.



FOLD  
HERE



When drilling its best to start with a small drill (2mm) first then open out with a 6-7mm drill

Use a backing board to prevent the wood splitting out.

Cut along here